2 x 6 In-Wall Installation

The UltraMD33 dehumidifier is placed into the wall opening.

Wall opening measures 14 $\frac{1}{2}$ " wide by 30 $\frac{1}{4}$ " tall. Only one side of the wall will be cut to make the opening.


Dehumidifier is secured to the wall using #10 wood screws.

Electrical wiring can run through knock out on back of dehumidifier or knock out on bottom of dehumidifier, depending on application. Electrical wiring can be hard-wired or connected to a standard 120V outlet with the included 10' power cord.

Drain hose can run through knock outs on back, side, or bottom of dehumidifier, depending on application.

The power and drain connections can be contained within the wall cavity if the dehumidifier is installed after new construction.

Diffuser cover is secured to the dehumidifier using either Phillips screws or Tamper Resistant screws.



2 x 4 Through the Wall Installation

The UltraMD33 dehumidifier is placed into the wall opening.

Wall opening measures 14 $\frac{1}{2}$ " wide by 30 $\frac{1}{4}$ " tall. Both sides of the wall will be cut through.

Dehumidifier is secured to the wall using #10 wood screws.

Electrical wiring can run through knock out on back of dehumidifier or knock out on bottom of dehumidifier, depending on application. Electrical wiring can be hard-wired or connected to a standard 120V outlet with the included 10' power cord.

Drain hose can run through knock outs on back, side, or bottom of dehumidifier, depending on application.

Diffuser cover is secured to the dehumidifier using either Phillips screws or Tamper Resistant screws.

Wall Mounting Bezel Kit or Rear Panel Kit are recommended with this type of installation.

